

STORAGE POD – STANDARD AND DELUXE MODEL MOUNTING INSTRUCTIONS



SOLID ROOF MOUNTING

- Step 1: Place the storage pod in the desired location on the R.V. roof (the mounting screws should go into the roof supports if possible).
- Step 2: In the lowest rib and equally spaced in the length of the storage pod, drill 3/16" holes through the bottom of the storage pod, into the roof of the R.V. Drill just enough so that the holes can be filled with silicone sealant.
- Step 3: Remove the storage pod.
- Step 4: Fill the holes in the R.V. roof with silicone sealant. Note: To help line up the storage pod holes with the holes in the R.V. roof, tap in a suitable sized finishing nail in each corner hole. Place the storage pod over the finishing nails and line up the holes.
- Step 5: With the screws through the metal washer and rubber grommets, screw into all holes except the corner holes. Remove the nails and screw into the corner holes.

SOFT ROOF MOUNTING

- Step 1: Place 3/4" sheet of plywood (cut to same size as the outside dimension of the storage pod) in the location on the R.V. roof you desire the storage pod.
- Step 2: Locate roof supports under 3/4" plywood. Measure the distance between supports. Mark this distance between supports on one side of the 3/4" plywood.
- Step 3: Drill holes through the plywood penetrating the roof just enough so that the holes can be filled with silicone sealant. Size of holes to be 3/16" over the size of screws to be used.
- Step 4: Fill holes with a silicone sealant and fasten plywood to roof using self-tapping screws. Lay a bead of silicone sealant around the edges of plywood.
- Step 5: Mount storage pod as noted in Solid Roof Mounting, beginning with Step 2.

WARNING

1. Prior to moving R.V., ensure that storage pod is securely mounted and the latches are securely fastened.
2. Please note that these mounting instructions are merely a suggested mounting procedure. Proper installation of the storage pod is the sole responsibility of the customer.